







## **APPLICATION INSTRUCTIONS**

GENERAL DESCRIPTION

- SUBJECT TO CHANGES OR DEVIATIONS

Application Instructions for Insitu® ES<sup>2</sup> & ElectroFin® E-Coat Spray Performance Repair Aerosol® (PRA)

## PRODUCTS FOR APPLICATION

- ElectroFin® E-coat repairs use ElectroFin® E-coat Black Performance Repair Aerosol® (IEA-BA-031)
- Insitu® ES2 repairs use Insitu® ES2 Performance Repair Aerosol® (IEA-AA-019)

## **SAFETY**

You must wear plastic gloves, goggles, and respirator type mask when working with Acetone and paint coatings.

## INSTRUCTIONS FOR APPLICATION

- Remove all burnt or damaged loose coating with a piece of Scotch-brite™ (scouring pad), emery cloth, or wire brush.
- 2. Wipe the affected area using Acetone with a cloth. As with all chemicals, to follow proper and safe procedures, refer to the Safety Data Sheet (SDS) for use of materials.
- 3. Cover or mask off areas to protect from overspray.
- 4. Shake can until ball rattles and continue shaking for 1 minute.
- 5. Remove the lid from the can.
- 6. Apply in short overlapping strokes at 2 to 4 inches away as necessary to cover the area. Slowly apply coating until it matches existing color. As with all chemicals, follow the instructions per manufacturer's guidelines.
- 7. Wait 30 seconds between layers, if additional layers are needed.
- 8. Remove masking materials being careful to not damage the area just coated.
- 9. Wait until the coating has cured (30 minutes) before placing into service.

INS75-186.2

ModineCoatings.com